


Rapid Repair Techniques Workshop


Work Zone Safety
Work Zone Traffic Impact Analysis
Work Zone Barriers


Paul Kelley Work Zone Safety Coordinator May 21, 2009

VDOT

Work Zone Safety









Work Zone Crashes

Top five charges in 2007:

- 1. Following too closely
- 2. Reckless driving exceeding safe speed
- 3. Failure to maintain control
- 4. Failure to yield right-of-way
- 5. Improper lane change





Best Practices for Designers

Design for actual traffic speeds when possible:

- Motorist will only reduce travel speeds if they perceive a need to.
- **▲** Make lane shifts and crossovers as long as possible.

If existing turn lanes are present, then they should be provided during construction.

9

VDOT

Best Practices for Designers

Look at the "Big Picture":

- **↓** Consider nearby routes and roadway corridors.
- **↓** Visit the site prior to beginning the design work.
- ↓ Visit the site once construction has begun is the design and TCP working?





Ask the question "Can we close this road to build this project?"

Work Zone Traffic Impacts

11

VDOT

What is Work Zone Traffic Impacts Assessment?

Overview of the Analysis Process

- Assess the work zone impacts and developing appropriate transportation management plans (TMPs) during project development.
- ♣ Monitor actual impacts during construction and making adjustments if necessary.
- **↓** Conduct performance assessments to track performance to improve work zone policies, procedures and practices.

Work Zone Traffic Impact Considerations


- Safety of Motorists/Pedestrians/Bicyclists and Highway Workers
- Mobility and Accessibility
- Constructability by building projects as effectively and efficiently as possible


13


VDOT

Traffic/Road User Cost Analysis Tools


- **↓ VDOT Permitted Lane Closure Hours**
- **▲ NCHRP Report 581**
- Virginia HUB − Highway User Benefit − Cost Analysis Worksheet (Currently Under Development)














Selecting Barriers, Barricades and Channelizing Devices

Energy Absorption's Vulcan Portable Barrier

- Temporary Steel Barrier Meets NCHRP 350 TL-3 criteria
- Deflection 3" (anchored) to 6' (free standing)
- Portable using one truck in lengths up 525'





Questions

Additional Information contact:

Paul Kelley
Email: Paul.Kelley@VDOT.Virginia.gov
Telephone: 804.786.8029

2



Rapid Repair Techniques Workshop

Work Zone Safety
Work Zone Traffic Impact Analysis
Work Zone Barriers

Paul Kelley Work Zone Safety Coordinator May 21, 2009